QUICK REFERENCE GUIDE // Non-touch screen Z-Line models





These steps have been provided to assist you with your Dejavoo non-touch screen payment device with AURA software. IMPORTANT: The terminal's idle prompt displays Credit and Sale options and a prompt to access the Services menu (F1). To change payment type, use the \downarrow arrow key to select the payment type you prefer. To change transaction type, press the \downarrow key until the transaction type you prefer appears.





MANUALLY ENTERED CREDIT SALE

- From the idle screen, input the Sale Amount and press Ok.
- 1. Input **Server** # and press **Ok**. Conditional on the terminal's configuration.
- If configured, terminal will prompt to Select or Input Tip amount.
- 3. From the multi pricing screen, select the payment method using the ↑↓ arrow keys and press **Ok**.
- 4. When the prompt to insert card appears, press **Ok** and you will get the enter card # prompt.
- 5. Manually input card #.
- 6. Follow the CNP prompts (input exp. date, ZIP code etc). *Conditional on the terminal's configuration.*
- 7. The transaction is processed. Sales receipts will print with details of the transaction.



CHIP CREDIT SALE

- From the idle screen, input the Sale Amount and press Ok.
- 2. Input Server # and press Ok. Conditional on the terminal's configuration.
- If prompted, confirm the Sale Amount by pressing F2 (YES) or F4 (NO). Conditional on the terminal's configuration.
- 4. If configured, terminal will prompt to **Select or Input Tip** amount.
- From the multi pricing screen, select the payment method using the ↑↓ arrow keys and press Ok.
- 6. Tap (contactless only) or insert chip card.
- 7. The transaction is processed. Sales receipts will print with details of the transaction.



DEBIT SALE

- Use the ↓ arrow key to highlight **Debit** on your terminal home screen and press **Ok**.
- 2. Input the Sale Amount and press Ok.
- 3. Input **Server** # and press **Ok**. Conditional on the terminal's configuration.
- From the multi pricing screen, select the payment method using the ↑↓ arrow keys and press Ok.
- 5. Tap (contactless only), swipe or insert chip card.
- If prompted, confirm the Sale Amount by pressing F2 (YES) or F4 (NO). Conditional on the terminal's configuration.
- 7. Cardholder inputs PIN on terminal PIN Pad or external PIN Pad and presses **Ok**.
- 8. The transaction is processed. Sales receipt will print with details of the transaction.



CREDIT CARD RETURN

- From your terminal home screen, press the key until **Return** appears.
- 2. Input the **Return Amount** and press **Ok**.
- Confirm the return amount by pressing F2 (YES) or F4 (CANCEL).
- 4. If prompted input **Manager Password** (1234 default).
- Tap (contactless only), insert, swipe or manually enter card #.
- 6. The transaction is processed. Return receipt will print with details of the transaction.

QUICK REFERENCE GUIDE // For non-touch screen Z-Line models





VOID CREDIT TRANSACTION (CARD PRESENT)

- 1. From your terminal home screen, press the key until Void appears.
- 2. Input Void Amount and press Ok.
- 3. Confirm void amount by pressing F2 (YES) or F4
- 4. If prompted, input Manager Password (1234 default).
- 5. Tap (contactless only), insert, swipe or manually enter
- 6. Confirm void amount by pressing F2 (YES) or F4 (NO).
- 7. The transaction is processed. Void receipt will print with details of the transaction.



VOID CREDIT TRANSACTION (CARD NOT PRESENT)

- 1. From the idle prompt, press F1 to access the Services
- 2. Use the ↑ arrow keys to highlight **Favorites** and press
- 3. Use the ↑ arrow keys to highlight Void CR/DB Trans
- 4. If prompted, input Manager Password (1234 default).
- 5. Use the ↑ ↓ arrow keys to select **By Transaction** # and press Ok.
- 6. Input Transaction # to be voided and press Ok.
- 7. If prompted, confirm the Void Amount by pressing F2 (YES) or F4 (NO). Conditional on the terminal's configuration.
- 8. If prompted, input Manager Password (1234 default).
- 9. The void is processed. Void receipt will print with details of the transaction.



REPRINT RECEIPT

- 1. From the idle prompt, press F1 to access the Services
- 2. Use the ↑ ↓ arrow keys to highlight **Favorites** and press
- 3. Use the ↑ ↓ arrow keys to highlight Reprint CR/DB Receipt and press Ok.
- 4. If prompted, input Manager Password (1234 default).
- 5. Use the $\uparrow \downarrow$ arrow keys to highlight desired option (Last, By Transaction # or By Card Number) and press Ok.
- 6. Transaction receipt prints.



CALL ME FEATURE (MUST BE ENABLED)

- 1. From the terminal main screen press the **F1** key.
- Use the ↑ arrow keys to highlight Managed Services and press Ok.
- 3. Use the $\uparrow \downarrow$ arrow keys to highlight **Call Me** and press **Ok**.
- 4. The terminal sends notification to the help desk and you will receive a call back from a representative with assistance.



TURN SERVER PROMPT ON/OFF

- 1. From the idle prompt, press F1 to access the Services
- 2. Use the $\uparrow \downarrow$ arrow keys to highlight **Core** and press **Ok**.
- 3. Use the $\uparrow \downarrow$ arrow keys to highlight **Applications** and press Ok.
- Use the ↑↓ arrow keys to highlight CREDIT/DEBIT/EBT and press Ok.
- 5. Use the $\uparrow \downarrow$ arrow keys to highlight **Setup** and press **Ok**.
- 6. If prompted, input Manager Password (1234 default).
- 7. Use the ↑ ↓ arrow keys to highlight **Trans Prompts** and press Ok.
- 8. Press Ok to select Clerks.
- 9. Press Ok to select Prompt.
- 10. Use the $\uparrow \downarrow$ arrow keys to highlight desired option and press **Ok**.
- 11. To return to the home screen press the times.



SETTLE DAILY BATCH

- 1. From the idle prompt, press F1 to access the Services
- 2. Use the ↑ ↓ arrow keys to highlight **Settlement** and press Ok.
- 3. Use the ↑ ↓ arrow keys to highlight **Settle Daily Batch** and press Ok.
- 4. If prompted, input Manager Password (1234 default).
- 5. Terminal communicates with the host.
- 6. Settlement Report prints.



PRINTING REPORTS

- 1. From the idle prompt, press F1 to access the Services
- 2. Use the $\uparrow \downarrow$ arrow keys to highlight **Reports** and press Ok
- 3. Use the $\uparrow \downarrow$ arrow keys to highlight desired report type (Daily Report or Summary Report) and press Ok.
- 4. If prompted, input Manager Password (1234 default).
- 5. Report prints.



POWER CYCLE TERMINAL

1. Press and hold the (4) key on the keyboard and release once terminal starts to reboot.



WI-FI ICON INDICATOR (WI-FI ENABLED UNITS)

Wi-Fi connected successfully.









